

0-25% manual outside air damper Cabinet Unit Heater



Features

Models RF and RS only

- Operational at 0% or 25% outside air
- Furnished with a 120V/60/1 synchronous motor that is wired to the blower to automatically open the damper when the fan starts
- When the power is off or interrupted, the damper returns to the closed position
- Located in bottom of floor mounted units only
- Damper motor always on right side when viewing unit from front side
- All listed dimensions are approximate and are subject to change without notice
- Modifications to the product specifications must be accepted by Zehnder Rittling at its base office

| Unit size | A | B | C | D |
|-----------|---------|--------|----|--------|
| 02 | 38-3/16 | 22-3/8 | 24 | 18-5/8 |
| 03 | 44-3/16 | 28-3/8 | 30 | 18-5/8 |
| 04 | 50-3/16 | 34-3/8 | 36 | 23-5/8 |
| 06 | 62-3/16 | 46-3/8 | 48 | 23-5/8 |
| 08 | 68-3/16 | 52-3/8 | 54 | 33-5/8 |
| 10 | 76-3/16 | 60-3/8 | 62 | 33-5/8 |
| 12 | 86-3/16 | 70-3/8 | 72 | 33-5/8 |

Specifications

- 20-gauge galvanized steel
- Foam gasket seal
- Galvanized steel damper handle with wing nut memory setting

